


## PARTS DIAGRAM:



**On/Off:** Turn the unit on and off

**Recording your own command:**

Turn on the unit, and push the mode button for 3 seconds, after a beep, you could record your own commands for 6 seconds.

To record clearly, please move close to the mic on the head of unit.

**Mode:** 3 working modes

**1. Ultrasonic mode**

Turn on the unit, the green light will be turned on and the unit is set

to be in ultrasonic mode to activate a high pitch sound audible only to dogs.

## 2. Audible mode:

push the mode button, the green light is turned off and the red light is turned on.

when the unit is activated by your dog, your recorded own command will play.


## 3. Ultrasonic and audible mode

push the mode button twice, the red and green lights will be turned on at the same time.

when the unit is activated by your dog, the pitch sound will be activated and then the dog will hear your recorded commands.

## Operation

Placing collar on dog: Simply adjust collar to appropriate size for your dog and either slide over your dogs head or unfasten the clip place on dog and clip again. (See diagram)



## To Replace Batteries:

1. Use screw to open battery compartment cover.
2. Remove old batteries and replace with four new LR44, 1.5V button cell batteries, negative side first.
3. Snap battery compartment cover back into place.
4. Screw up the cover.